



Cea UPMC

LPNHE

Device and process TCAD simulation experiences at Fondazione Bruno Kessler

Giovanni Paternoster LPHNE – Paris, 7 Sept 2016


CMM CENTRE FOR MATERIALS AND MICROSYSTEMS

FONDAZIONE FONDAZIONE Bruno Kessler (FBK)



Fondazione Bruno Kessler Centre for Materials and Microsystems

FONDAZIONE Fondazione Bruno Kessler (FBK)






FBK Organization

Scientific and
Technological AreaHumanities
Area



CMM CENTRE FOR MATERIALS AND MICROSYSTEMS

CMM: The Four Research Lines




FONDAZIONE BRUNO KESSLER




Research topics


Two main platforms:

Single-photon light sensors



High-energy radiation detectors





R&D initiatives on:

TeraHertz detectors

CENTRE FOR MATERIALS AND MICROSYSTEMS

CMM

Low-power imaging Graphene-based detector TRL 9 TRL 8 TRL 7 TRL 7 TRL 6 TRL 5 TRL 4 TRL 3 TRL 2 TRL 2 TRL 1



Research Units

The activity is carried out in two Research Units:





~20 people (electronic eng, physicists)

~40 people (physicists, chemists, technicians)



CMM: Micro Nano characterization and fabrication Facility (MNF) Doms ISO 9001-2008

Two separate clean rooms

- 500m² of clean room (class 10-100)
- 200m² of clean area (class 100-1000) equipped for MEMS technology

<u>6-inch wafers (Si, Quartz, Glass) – 0.35 um processing</u>

Dry/wet oxidation
sputtering Metallization
Diffusion

•LPCVD

•PECVD

Projection lithography: CD 2μm
Stepping lithography: CD 350nm
Ion Implantation
Dry/wet etching










Technologies

Silicon-based detector in full-custom technology




CENTRE FOR MATERIALS AND MICROSYSTEMS

CN

Silicon Strip Detectors

AMS experiment (@ISS)



Limadou experiment (@CSES)




ALICE experiment (@LHC)

Custom productions for industry

Technologies & Competencies

Full Custom Silicon Technology




State-of-the art CMOS Technologies



Analog and Digital IC Design

130nm-350nm external Fab

Parametric Testing Functional Testing








CMM CENTRE FOR MATERIALS AN

Workflow for device developing





Why TCAD simulations?

• Very powerful tool for:

- design optimization of the device
- Problem solving
- Deep understanding of the device physics

• Simulating sensors:

- Avoid trivial errors and mistakes
- Reduce the number of splits and iterations during the fabrication (save time & money)



Simulations

Process technology Simulations

- Example 1: Oxidation
- Example 2: Trench Oxidation LOCOS
- Example 3: Ion Implants


Device Simulations

- Case Study 1: Multi Guard Ring Design for silicon detectors
- Case Study 2: Silicon Solar Cells for CPV

EVALUATE REVEALED A CONTRACTORY Simulations


• Example 1: Oxidation

Well known process. Silvaco is not striclty required




 Problem (doping inversion) n-type wafers (1e12 atoms/cm-3) after the oxidation turn into p-type!!!

• Example 1: Oxidatior




• Example 2: Trench Oxidation (LOCOS)



SiPM (matrix of SPADs connected in parallel)

SiPM



Trench for SPAD isolation in a

CMM CENTRE FOR MATERIALS AND MICROSYSTEMS

• Example 2: Trench Oxidation (LOCOS)


Oxidation of the trench internal surfaces. We would oxidize only the trenches but not the wafer top surface.

deposit oxide thick=0.02 dy=0.001 deposit nitride thick=0.03 dy=0.001 etch nitride start x=2.2 y=0.05etch cont x=2.8 y=-0.05etch cont x=2.8 y=0etch done x=2.2 y=0etch oxide start x=2.2 y=-0.05etch cont x=2.8 y=-0.05etch cont x=2.8 y=0etch done x=2.2 y=0etch done x=2.2 y=0etch cont x=2.8 y=0etch cont x=2.8 y=0etch cont x=2.8 y=3etch done x=2.2 y=3

CENTRE FOR MATERIALS AND MICROSYSTEMS


"LOCOS" stands for "Local Oxidation of Silicon" The areas of the Si that are not to be oxidized must be protected by SiN that does not allow oxygen diffusion.

• Example 2: LOCOS





• Example 2: LOCOS



Process Technology Simulations Example 3: Shallow junction for UV sensitive photodetcors

UV light generated carriers in the first nm of Silicon

FONDAZIONE


CMM

CENTRE FOR MATERIALS AND MICROSYSTEMS

Is stricity necessary to create a shallow junction in order to increse the QE in the VUV range

Low energy Boron implant through a screen oxide layer


```
deposit oxide thick=0.05 dy= 0.001
implant boron dose=5e14 energy=10
tilt=7 rotation=0 crystal unit.damage \
dam.factor=0.8 monte n.ion=100000
smooth=0.4
```





Process Technology Simulations

Example 3: Shallow junction creation for UV sensitive photodet.






• Case study 1: Multi Guard Ring design


In future HEP experiments Si tracking detectors will be operated in a very harsh radiation environment, which leads to surface damage in Si detectors which in turn change the full depletion voltage and the Breakdown Voltage

GOAL: design detectors with Breakdown Voltage > 1000V also after radiation damage





• Case study 1: Multi Guard Ring design






• Case study 1: Multi Guard Ring design

• Mesh refinement: Very critic under the oxide due to the high Electric field


INO KESSI FE






- Case study 1: Multi Guard Ring design
- First structure:

No Field Plate on the guard ring





well working fornot-irradiateddevices.But afterirradiation...

CMM CENTRE FOR MATERIALS AND MICROSYSTEMS


Case study 1: Multi Guard Ring design

• Irradiated device

NO KESSI FE

Increase oxide charge from 5e10 to (Nox=1e12)

the breakdown voltage falls down to 470V !






- Case study 1: Multi Guard Ring design
- Optimized structure

Tuned parameters:


- Guard ring pitch
- P-stop width
- Field Plate





• Case study 1: Multi Guard Ring design

• Optimized structure:




Breakdown = 1270 Volts After irradiation!

CMM CENTRE FOR MATERIALS AND MICROSYSTEMS




- Case study 1: Multi Guard Ring design
- Optimized structure:

Detail of the Electric Field at the first guard ring





• Case study 2: Silicon Solar Cell for CPV




Project HCSC (2009) Project iSiCPV (2012-2014)

System Characteristics:


- Small mirrors 7 cm high.
- The illuminated spot size is about 16mm² wide.
- The light is concentrated at ≈ 160 Suns.
- Many assemblies can be used to obtain a solar panel of standard dimensions.








Case study 2: Silicon Solar Cell for CPV





• Case study 2: Silicon Solar Cell for CPV



Optimized Parameters:

- Base doping
- Cell thickness
- Back surface Field doping
- Front metal grid geometry
- Finger Spacing

#wafer thickness
set wb= 280
#finger spacing
set pitch= 80.0
#metal thickness
set hm= 4.0
#Finger width
set wf= 5.0

#Material and Doping
bulk doping
set dop_bulk = 3.255e+16
set BSFp = 0

bulk lifetime
set tau = 1e-4

CMM CENTRE FOR MATERIALS AND MICROSYSTEMS

Case study 2: Silicon Solar Cell for CPV


р

Simulations tuning with real experimental values

Recombination parameters

Bulk minority carrier lifetime 60 µm $10^{3} {\rm ~cm/s}$ Front surface (passivated) recombination velocity Recombination velocity at the metal- $3 \cdot 10^6$ cm/s silicon interface

SET MATERIAL material Silicon TAUN0=\$tau TAUP0=\$tau nc300=3.2e19 nv300=1.83e19 eg300=1.119 copt=1.1e-14 material material=aluminum real.index=1.39 imag.index=1.51




CMM

CENTRE FOR MATERIALS AND MICROSYSTEMS


Case study 2: Silicon Solar Cell for CPV

LINO KESSI FE





- Case study 2: Silicon Solar Cell for CPV
- Final Step: fabrication of the optimized solar cell & characterization





CMM


Device Simulations

- **Case study 2: Silicon Solar Cell for CPV**
- **Consideration:**

TCAD simulation is not only a powerful tool for device optimization.



New effects of Jsc superlinearity under concetrated light investigated by means of TCAD simulations



G. Paternoster et al., "Fabrication, characterization and modeling of a silicon solar cell optimized for concentrated photovoltaic applications", Solar Energy Materials and Solar Cells, Volume 134, March 2015, Pages 407-416. CENTRE FOR MATERIALS AND MICROSYSTEMS



Thank you for your attention!