

FAST BEAM DEFLECTION FOR MITIGATION OF PARAMETRIC INSTABILITY

GDR ONDES GRAVITATIONNELLES 13TH MARCH 2021

MARGHERITA TURCONI

THOMAS HARDER, REMI SOULARD, WALID CHAIBI


Outline

- Introduction:
 - Parametric instability (PI), PI Mitigation strategies.
- PI mitigation by radiation pressure
- 2D fast beam deflection
- Conclusion
- Perspectives

Introduction

PI: 3 mode instability

- Where? In optical cavities (optomechanical systems)



Evans et al, Phys. Lett. A, 374(4), 665-671 (2010)

- if
- ω_0 and ω_1 resonant in the cavity
 - Matching between mechanical and optical mode shapes
- Growing amplitude of Ω_m and ω_1

Introduction

PI: parametric gain

Mirror Quality Factor

Power in the cavity


Geometrical Overlap coefficient With the n^{th} optical Mode

$$\text{Gain } R_m = \frac{8\pi Q_m P_{\text{arm}}}{M \Omega_m^2 c \lambda} \sum_{n=1}^{\infty} \Re[G_{\text{cav}}] B_{m,n}^2$$

Mirror Mass

Mechanical frequency

Sum over all optical modes



Instability: $R > 1$

PI Rise time: $\tau_{\text{PI}} = \frac{2Q_m}{\Omega_m (R_m - 1)}$

[Braginsky et al., PRL 111, 101102 (2013)]
[Evans et al., PRL 111, 101102 (2013)]

Introduction


PI Mitigation strategies

Passive methods:


- Thermal tuning (changing radius of curvature)
- Acoustic Mode Dampers (changing Q of mechanical modes)

Active methods:

- Electrostatic actuators




S. Gras et al, Phys. Rev. D 92, 082001 (2015)
S. Biscans et al. Phys. Rev. D. 100, 122003 (2019)



C. Blair, et al, Phys. Rev. Lett. 118, 151102 (2017))

Introduction


PI Mitigation: thermal tuning



O1: LIGO observed PI at 50kW, thanks to this technique the intracavity power was increased to 100 kW

Introduction


PI Mitigation: Acoustic Mode Dampers (AMD)



1% degradation of thermal noise

25% loss factor

Piezo+ reaction mass





[S. Biscans PhD Thesis 2018]

In 3rd generation detectors thermal noise contribution from dampers can be a significant issue.

Introduction

PI Mitigation: Electrostatic actuators



- Predicted force: 10 nN rms
- Actual force : 0.03 nN
- Insignificant noise contribution to interferometer output
- Limit: fixed position of actuators

Introduction


PI Mitigation strategies

Passive methods:


- Thermal tuning (changing radius of curvature)
- Acoustic Mode Dampers (changing Q of mechanical modes)

Active methods:

- Electrostatic actuators
- Damping system based on radiation pressure




S. Gras et al, Phys. Rev. D 92, 082001 (2015)
S. Biscans et al. Phys. Rev. D. 100, 122003 (2019)




C. Blair, et al, Phys. Rev. Lett. 118, 151102 (2017))

PI damping by radiation pressure




Fast 2D Laser deflection Requirements

- Small ratio $\frac{\text{beam divergence}}{\text{scan angle}}$




Fast 2D Laser deflection Requirements

- Small ratio $\frac{\text{beam divergence}}{\text{scan angle}}$




Fast 2D Laser deflection Requirements

- Small ratio $\frac{\text{beam divergence}}{\text{scan angle}}$




Fast 2D Laser deflection Requirements

- Small ratio $\frac{\text{beam divergence}}{\text{scan angle}}$
- Deflection in random access \rightarrow optimal scan pattern
- High deflection rate: device able to damp mechanical mode up to few hundreds of kHz



Fast 2D Laser deflection Requirements


- Small ratio $\frac{\text{beam divergence}}{\text{scan angle}}$
- Deflection in random access \rightarrow optimal scan pattern
- High deflection rate: device able to damp mechanical mode up to few hundreds of kHz
- Radiation force of some nN rms \rightarrow deflected beam of several W



Fast 2D Laser deflection

AOM as deflector


→ Diffraction of an electromagnetic wave by an acoustic wave



→ Chosen AOM has a rise time of 33 ns and $\theta_{max} = 34$ mrad

Fast 2D Laser deflection

Deflection Efficiency of AOM




15 % flatness of the deflection curve

→ Amplitude of RF signals can be adjusted to control the deflection efficiency

Fast 2D Laser deflection

RF driver: USRP


- **U**niversal **S**oftware **R**adio **P**eripheral (Software Defined Radio Reconfigurable Device)
- Controlled via a software on linux machine



Fast 2D Laser deflection


RF driver: USRP

- **U**niversal **S**oftware **R**adio **P**eripheral (Software Defined Radio Reconfigurable Device)
- Controlled via a software on linux machine
- Frequency switch within $\sim 2\text{ns}$ (exponential decay)





Fast 2D Laser deflection

Experimental setup



Fast 2D Laser deflection


Deflection transition time



→ minimal transition time of 50ns between two arbitrary deflection spots

→ Result obtained with an input spot size of 200 μm $\rightarrow \frac{\text{beam divergence}}{\text{scan angle}} = \frac{1}{6}$


Fast 2D Laser deflection Results



- RF power adjustment for homogeneous deflection power ($\sim 1\%$)
- 24,2% overall optical deflection efficiency
- Full scan angle of 34mrad
→ beam spot on mirror $\sim \frac{1}{6}$

Fast 2D Laser deflection Results

Camera 15cm after Deflector





scan on florescence card



Fast 2D Laser deflection

High Power Deflection





- Maximal deflected beam of 3.6 W with 16.7 W input power
- Observing Thermal lens on 0. order deflection

Conclusion


2D deflection system

- Small $\frac{\text{beam divergence}}{\text{scan angle}} = 1/6$
- Deflection in random access
- High speed: deflection time = 50 ns
- High power deflected beam: 3,6 W \rightarrow 24 nN




Perspectives

- Use the 2D deflection device to detect the vibrations of a suspended mirror in a vacuum chamber → identification of the mechanical modes
- Test the device applying radiation pressure force to excite/damp a mechanical mode
- Optimize the efficiency (find best spatial and temporal overlap strategy)



- Implement power stabilization



Thank you for your attention