

TCAD Simulations: Applications at FBK


Matteo Centis Vignali ¹

SIMDET 2020
LPNHE 01.12.2021




¹mcentisvignali@fbk.eu







FBK is here!




www.fbk.eu


Silicon Detector Technology at FBK



Pixel




Silicon Photomultipliers




*Silicon Drift
Detectors*



*Single and Double Side
Microstrip*



3D-detectors



LGAD



Micro Nano Facility

Two separate clean rooms


- 500m² of clean room (class 10-100)
- 200m² of clean area (class 100-1000) equipped for MEMS technology

6-inch wafers (Si, Quartz, Glass) – 0.35 μ m processing

- Dry/wet oxidation
- sputtering Metallization
- Diffusion
- LPCVD
- **PECVD**
- Projection lithography: CD 2 μ m
- Stepping lithography: CD 350nm
- **Ion Implantation**
- Dry/wet etching



Where does Simulation Fit?



Powerful tool



- Design optimization of the device
- Problem solving
- Understanding of the device physics

Simulating sensors

- Avoid trivial errors and mistakes
- Reduce the number of splits and iterations during fabrication
⇒ **save time & money**

Process Simulation Example 1: Oxidation

...well known process, TCAD not strictly required...



```
#
diffus time=50 temp=500 t.final=1000 nitro
#
diffus time=120 temp=1000 dryo2
```

Problem: n-type wafers ($\approx 10^{12} \text{cm}^{-3}$) sometimes behave as p-type after oxidation

Process Simulation Example 1: Oxidation


Hypothesis test: Boron contamination in the furnace
(less than 1 ppm)

```
#  
diffus time=50 temp=500 t.final=1000 nitro\  
    c.boron=1.0e16  
#  
diffus time=120 temp=1000 dryo2
```

Test solution: oxidate during ramp
⇒ diffusion barrier


```
#  
diffus time=50 temp=500 t.final=1000 dryo2\  
    c.boron=1.0e16  
#  
diffus time=120 temp=1000 dryo2
```

Section from oxidation_avec_rampO.str (deleted)
Data from multiple files




Silicon Photomultipliers (SiPM)

- Light detection with single photon sensitivity
- Array of single photon avalanche diodes (SPAD) connected in parallel
- Geiger mode operation
- Trench isolation to avoid optical cross talk



Trenches between SPAD cells
width $< 1 \mu\text{m}$, aspect ratio > 5



These will be filled with oxide
(oxidation + deposition)

Trench oxidation:

ideally oxidate only the inside of the trench

⇒ put nitride as diffusion barrier

```
deposit oxide thick=0.02 dy=0.001
```

```
deposit nitride thick=0.03 dy=0.001
```

```
etch nitride start x=2.2 y=-0.05
```

```
etch cont x=2.8 y=-0.05
```

```
etch cont x=2.8 y=0
```

```
etch done x=2.2 y=0
```

```
etch oxide start x=2.2 y=-0.05
```

```
etch cont x=2.8 y=-0.05
```

```
etch cont x=2.8 y=0
```


```
etch done x=2.2 y=0
```

```
etch silicon start x=2.2 y=0
```

```
etch cont x=2.8 y=0
```

```
etch cont x=2.8 y=3
```

```
etch done x=2.2 y=3
```




Oxidation in only in some regions:
LOCOS → LOCAL Oxidation of Silicon

Trench oxidation:

diffus time=150 temp=1000 dry



- Beak height depends on initial oxide and nitride thickness
- Higher beak \Rightarrow higher stress and dislocations
 \Rightarrow worse device performance

Optimize!




Process Simulation Example 2: Trench Oxidation & LOCOS

Deposit more oxide




Low Gain Avalanche Detectors




- Silicon detectors with charge multiplication
- Gain ≈ 10
- Gain layer provides high-field region
- Junction Termination Extension improves stability

- **Improve SNR of the system**
(When the sensor shot noise is not dominating)
- Noise and power consumption
 \Rightarrow low gain

Double Sided LGADs



- Continuous gain area in the active region \Rightarrow 100% fill factor
- Double sided process
- Active thickness is the wafer thickness
- Readout side is ohmic
- Design not optimal for timing applications
- Readout side separated from LGAD side \Rightarrow no restrictions on channel dimensions



- Produced double sided LGADs dedicated to x-rays
- Several strip and pixel sensors geometries
- Different gain structure designs

Two examples: strip sensors signal, gain structure optimization


Double Sided LGAD Strip Signals

Aim: determine signal shape and duration at different positions

- Make structure with 4 strips
- Bias it to 200 V
- Generate carriers using photogeneration
- Record signal on the strips
- Repeat at different positions

Two “parts” of the signal:

- Primary ionization
- Multiplication holes




Double Sided LGAD Strip Signals

Aim: determine signal shape and duration at different positions

- Make structure with 4 strips
- Bias it to 200 V
- Generate carriers using photogeneration
- Record signal on the strips
- Repeat at different positions

Two “parts” of the signal:


- Primary ionization
- Multiplication holes




Double Sided LGAD Strip Signals

Photogeneration close to left strip, 200 V bias

Gain



Charge multiplication model turned off




- Same fields in both structures
- Shorter signals for sensor without gain
- With this it is possible to extract gain


Double Sided LGAD Strip Signals

Photogeneration close to left strip, 200 V bias

Gain



Charge multiplication model turned off



- Same fields in both structures
- Shorter signals for sensor without gain
- With this it is possible to extract gain

Device Simulation Example: Signal in Strip Sensor


- n-type bulk strip sensor
- Built for didactics \Rightarrow toy implants and geometry
- Similar idea (and code) as the double sided LGAD

Detector building (Devedit)

- make 1/2 strip, mesh and save structure
- load structure
- mirror
- mesh
- save structure
- repeat until 4 strips are present
- assign electrodes names to Al regions
- refine mesh for photogeneration
- save structure

Realistic implant profiles used when needed

Doping density




Always needed before starting:

- load structure file
- define material properties (type of material, lifetimes)
- define physical models
- set all electrodes to 0V (neutral)
- define interface properties (charge and surface recombination velocities)




[suasnews ]

- preparation steps
- select output variables
- define numerical methods
- initialize the solution
- first bias points in small steps (bias applied to backside)
- ramp up the bias and save solution files for interesting values




- preparation steps
- select output variables
- define numerical methods
- initialize the solution
- first bias points in small steps (bias applied to backside)
- ramp up the bias and save solution files for interesting values

E field 100V log scale




- preparation steps
- define numerical methods and specify maximum time interval (time discretization)
- load solution file for the bias point
- load photogeneration table
- start the transient simulation
- “flash the light” (beam on and off)
- run the simulation to capture the signal
- optional: save the solution files at various times

Charge injection close to backside (200V)




What we will see:

- Concentration (log scale) of electrons and holes
- Drift
- Diffusion
- Signal current
- Effects of mesh
- Note: the signal starts the moment the charge starts to move



What we will see:


- Concentration (log scale) of electrons and holes
- Drift
- Diffusion
- Signal current
- Effects of mesh
- Note: the signal start the moment the charge starts to move





Strip Sensor Bottom Injection

- Bias 200 V
- Charge generated in small volume \rightarrow Similar to x-ray, or red TCT
- Charge deposit ≈ 275 eh-pairs $\rightarrow \approx 1$ keV


Time 0.2 ns Electrons





Holes




Time 0.3 ns Electrons





Holes




Time 0.8 ns Electrons





Holes




Time 1.3 ns Electrons





Holes




Time 1.8 ns Electrons





Holes




Time 2.3 ns Electrons





Holes




Time 2.8 ns Electrons





Holes




Time 3.3 ns Electrons





Holes






Time 3.8 ns Electrons




Holes








Time 4.8 ns Electrons





Holes




Time 5.3 ns Electrons





Holes




Time 5.8 ns Electrons





Holes




Time 6.3 ns Electrons





Holes




Time 6.8 ns Electrons





Holes




Time 7.3 ns Electrons





Holes




Time 7.8 ns Electrons





Holes




Time 8.3 ns Electrons





Holes




Time 8.8 ns Electrons





Holes




Time 9.3 ns Electrons





Holes




Time 9.8 ns Electrons





Holes




Time 10.3 ns Electrons





Holes




Time 10.8 ns Electrons





Holes




Time 11.3 ns Electrons





Holes




Time 11.8 ns Electrons





Holes




Time 12.3 ns Electrons





Holes




Time 12.8 ns Electrons





Holes




Time 13.3 ns Electrons





Holes




Time 13.8 ns Electrons





Holes




Time 14.3 ns Electrons





Holes




Time 14.8 ns Electrons





Holes




Time 15.3 ns Electrons





Holes




Time 15.8 ns Electrons





Holes




Time 16.3 ns Electrons





Holes




Time 16.8 ns Electrons





Holes




Time 17.3 ns Electrons





Holes



Time 17.8 ns Electrons




Holes



- preparation steps
- load solution file for bias point
- raise the potential of the interested electrode by 1V (same steps as for biasing)
- save solution file
- difference in potential between files
⇒ weighing potential
- difference in electric field between files
⇒ weighing field

Note: it is not necessary to use 1V, but other values need normalization afterwards

Weighting potential (200V, left strip)




Extract the weighing field and potential (Atlas + Tonyplot)

- preparation steps
- load solution file for bias point
- raise the potential of the interested electrode by 1V (same steps as for biasing)
- save solution file
- difference in potential between files
⇒ weighing potential
- difference in electric field between files
⇒ weighing field

Note: it is not necessary to use 1V, but other values need normalization afterwards


Weighting potential (200V, left strip)



- preparation steps
- load solution file for bias point
- raise the potential of the interested electrode by 1V (same steps as for biasing)
- save solution file
- difference in potential between files
⇒ weighting potential
- difference in electric field between files
⇒ weighting field

Note: it is not necessary to use 1V, but other values need normalization afterwards



Weighting field (200V, left strip)




Process & Device Simulation Example: Gain Layer Optimization

- Optimization for x-ray applications
- Gain dose to be adjusted for device thickness
- Implants dose and energy to be adjusted for different process splits
- **Provide a starting point for the process split table**

Double Sided LGADs for X-rays



- Optimization for x-rays
- One possibility: gain structure as narrow as possible
- Few variations in the batch



Gain Extraction

“Analytical”

- α, β from bias simulation
- Gain calculation using McIntyre 1966

$$M(x) = \frac{\exp \left[- \int_x^w \alpha - \beta dx' \right]}{1 - \int_0^w \alpha \exp \left[- \int_{x'}^w \alpha - \beta dx'' \right] dx'}$$

- Ideal case, low injection
- Faster simulation \Rightarrow more attempts

Fully simulated

- Simulate same structure with and without gain
- Transient or steady state simulations with photogeneration
- Ratio of integrated signals / currents
- More realistic: diffusion, density effects...
- Computing intensive

The “analytical” path was chosen

Simulation Workflow


For each process variation:

Process Simulation (Athena)


- Make mesh
- Create substrate
- Backside implant (bulk contact)
- Screen oxide
- Implants
- Annealing
- Remove oxide
- Save structure file

Device Simulation (Atlas)

- Make mesh
- Create substrate
- Declare electrodes
- Import doping from structure file
- Preparation steps
- Bias
- Extract α, β at given bias values



Electrons gain



Quite sensitive to:

- Gain layer position
- Doping concentration
(left: $\approx 2\%$ dose variation)
- Impact ionization model

Process Simulations

- Problem solving
- Process optimization

Device Simulations

- Estimation of detector properties
- Understanding the detector structure

- **TCAD is a useful tool in detector fabrication**
- Reduce the number of splits and iterations during fabrication
⇒ save time & money

**Not everything can be simulated:
process variations are still necessary to explore the phase space**

Backup Material

Weighting Field

Math construct that relates charge movement to induced current on electrodes

- Determines the signal shape
- Depends on the sensor geometry
- Concept from vacuum tubes
- Shockley (1938) ^{FBK} Ramo (1939) ^{FBK}
- Extensions in recent years to account for different effects

To calculate:

- Set all electrodes to 0V
- Set electrode of interest to 1V
- Solve equations (disregard space charge)

For the i-th electrode

$$i_i(t) = Nq_e \vec{E}_{w,i} \cdot \vec{v}$$

$$Q_i = \int_{t_0}^t i_i(t') dt' = Nq_e [\phi_{w,i}(\vec{r}(t)) - \phi_{w,i}(\vec{r}(t_0))]$$



$$\vec{E}_{w,i} = -\vec{\nabla} \phi_{w,i} \quad \vec{v} = \frac{d\vec{r}}{dt}$$

- $\vec{E}_{w,i}$ with \vec{v} determine signal shape
- $\Delta \phi_{w,i}$ determines the induced charge
- $[\vec{E}_{w,i}] = \text{cm}^{-1}$
- $[\phi_{w,i}] = \text{dimensionless}$

Note: these are NOT the fields determining carrier movement

Weighting Field Pad Diode (Top Electrode)



Weighting Potential



- Simple geometry
- Linear potential \Rightarrow Charge proportional to path
- Constant field \Rightarrow Current proportional to $|\vec{v}|$


Weighting Field Pad Diode (Top Electrode)

Weighting Field



- Simple geometry
- Linear potential \Rightarrow Charge proportional to path
- Constant field \Rightarrow Current proportional to $|\vec{v}|$



Weighting Potential



- Weighting potential for strip L
- Asymmetry due to boundary conditions



- Peaked potential toward strip side \Rightarrow most of charge induced in the space closest to the strip
- Different sign of field \Rightarrow Different sign of signal possible \rightarrow Bipolar signals on some strips

Weighting Potential





- Peaked potential toward strip side \Rightarrow most of charge induced in the space closest to the strip
- Different sign of field \Rightarrow Different sign of signal possible \rightarrow Bipolar signals on some strips

Weighting Field





- Peaked potential toward strip side \Rightarrow most of charge induced in the space closest to the strip
- Different sign of field \Rightarrow Different sign of signal possible \rightarrow Bipolar signals on some strips

Weighting Field



- Peaked potential toward strip side \Rightarrow most of charge induced in the space closest to the strip
- Different sign of field \Rightarrow Different sign of signal possible \rightarrow Bipolar signals on some strips

X-ray Attenuation Length



http://henke.lbl.gov/optical_constants/atten2.html